


INSTRUCTION MANUAL



AC INVERTERS
0.75 to 7.5 kW

Please read these
instructions before
installation and use.
If in doubt contact
your supplier.

The drives you'll swear by - not at!

List of Contents

	Page
1. General	1
2. Specification	1
3. Principle of Operation	2
4. Motor Rating	4
5. Inverter Installation	4
6. Commissioning	9
6.1 Starting a Drive	9
6.2 Adjustments	9
7. Reversing	10
8. Speed Control Input Variations	10
9. Torque Control	10
10. External Speed Signal	11
11. External Torque Signal	11
12. Tachogenerator Feedback	11
13. External Inhibit	11
14. External Trip	12
15. External Reset	12
16. Frequency Synchronisation	12
17. Economy Mode	12
18. Electronic Pushbutton Control	13
19. LED Diagnostic Indicators	13
20. Braking Unit IB1	14
21. IN3 (Control PCB) Block Diagram	16
22. Fault Finding Chart	17

PLEASE READ THESE INSTRUCTIONS
BEFORE INSTALLATION AND USE. IF IN
DOUBT CONTACT YOUR SUPPLIER.

1. General

The Jaguar series of PWM Sine Wave variable frequency inverters for the control of A.C. Motors covers the range 0.75-7.5kw. The 0.75kw to 1.5kw are available with single phase or three phase inputs. All units have isolated electronics, current limit, overload protection and a wide range of standard features. All units above 11A are fan cooled.

2. Specification

Standard Range

TYPE	VN75	VN110	VN150	VL75	VL110	VL150	VL220	VL370	VL550	VL750
Input	1PH 220/240V $\pm 6\%$ 50/60Hz			3PH 380/415V $\pm 6\%$ 50/60Hz						
Max. Output Line Voltage	3PH 220/240V			3PH 380/415V						
Motor Kw	0.75	1.10	1.50	0.75	1.10	1.5	2.20	3.70	5.50	7.50
Rated Current A	3.6	4.8	6.5	2.1	2.8	3.8	5.6	8.6	12.0	16.0
Cooling	Natural Ventilation								Fan	

Low Voltage Range

TYPE	VNO1	LVL02	LVL03	LVL05
Input	3PH 220/240V $\pm 6\%$ 50/60Hz			
Max. Output Line Voltage	3PH 220/240V			
Motor H.P.	1	2	3	5
Rated Current A	5	8	11	17
Cooling	Natural Ventilation		Fan	

High Voltage Range

TYPE	HVL03	HVL05	HVL075	HVL10
Input	3PH 440/460V $\pm 6\%$ 50/60Hz			
Max. Output Line Voltage	3PH 440/460V			
Motor H.P.	3	5	7.5	10
Rated Current A	4.8	7.6	11.5	15.0
Cooling	Natural Ventilation		Fan	

Frequency Range	2-100Hz $\pm 0.5\%$ (2-120Hz for 60Hz motors)
Overcurrent	1.5 x F.L.C. for 20 sec.
I/P Power Factor	0.95 Lag. 0.86 Lag for VL550-750, LVL 05 HVL075/10
Temperature Range	-10 to + 40°C derate 1.5%/°C from 40-60°C max.
Humidity	85% R.H. at 40°C Non Condensing
Altitude	Above 1000 meters derate by 1%/100 meters
Control Method	PWM Sine Wave 2-48Hz merging Quasi-square 48-100Hz

Control Inputs -(Isolated)	Set Speed (Frequency)	0 to +10V, 4-20mA 0-3000Hz
	Set Torque	0 to +10V
Control Outputs -(Isolated)	Forward/Reverse	N/O Contact or 0/15V Logic Signal @ 5mA
	Run/Inhibit	N/O Contact or 0/15V Logic Signal @ 5mA
	External Trip	N/C Momentary Contact or 0/15V Logic Signal @ 5mA
	External Reset	N/O Momentary Contact or 0/15V Logic Signal @ 5mA
	Tacho F.B.	20V/1000R.P.M. (Standard) 60V Max.
Adjustments	Speed (Frequency)	0 to +10V (100 μ A) $\pm 10\%$ & 0-3000Hz
	Torque	0 to -10V (100 μ A) $\pm 20\%$ from 10-50Hz
	Fault	C/O Contact 240V 3AAC
	Reference Voltage	+ 10V @ 2mA
	Ramp Output	0 to + 10V @ 5mA
Adjustments	Min Speed	2Hz to 0.3 F Max
	Ramp Up	1-300 Sec. Linear

Ramp Down	1-300 Sec. Linear
Max Speed	40-100Hz (120Hz with 60Hz Motors)
Low Freq Boost	0-0.15 x Max Motor Voltage
Current Limit	0.75-1.5 x FLC

Diagnostic

Power On	⚡
Run	↻
Over Current	> I
Over Voltage	> V
Overload	> I x t
Under Voltage	< V
Over Temperature	Models VL550-750, LVL03/05, HVL03-10

3. Principle of Operation

The synchronous speed (N) of a three phase induction motor is determined by the number of poles (P) and the frequency F of the applied voltage.

$$N = \frac{120F}{P}$$

To obtain true infinitely variable speed it is necessary to change the frequency of the applied voltage. However when reducing frequency from 50Hz it is also necessary to reduce the applied voltage in proportion in order to maintain constant flux and avoid magnetic saturation of the motor. Similarly when increasing frequency above 50Hz the applied voltage should be increased, however, we are limited to the maximum voltage of the supply hence the torque speed characteristic 0/100Hz is approximately as shown in Fig 2. Fig 3 shows the relationship between frequency and applied voltage. Low frequency voltage boost is required to overcome the effect of motor resistance. Fig 1 shows the block diagram of the Jaguar inverter. The input supply is rectified by a single or three phase rectifier the output of which is smoothed by C5/8. At switch on this capacitor is initially charged via R3 which is shorted out by RL1 after the start up delay (TD). The voltage across the capacitor is approximately 340 or 580V for single phase and three phase inputs respectively. This voltage is fed to the transistor inverter via current limiting inductance L. The D.C. current and voltage are monitored and isolated from the electronic control circuits.

The transistors are switched in such a way that each output line voltage is as shown in Fig 4. This results in a motor line current as shown in Fig 5 the ripple being limited by motor inductance. The flywheel diodes across each transistor provides a path for the inductive current, hence when the inverter is running at low power factor (light load) the current drawn by the D.C. link is low due to the current feed back from these diodes. Also when the frequency is reduced the motor will regenerate the reverse current flowing through the flywheel diodes into the D.C. link. If this is allowed to happen the D.C. link voltage will rise and the inverter will trip out on overvoltage. With the Jaguar, reverse current in the D.C. link is carefully controlled thus avoiding tripping out with regenerative loads. The switching signals for the power transistors consist of ON and OFF pulses and are isolated from the electronic circuits by pulse transformers. The P.W.M. waveforms are generated in a custom I.C. which is in turn controlled by a frequency demand oscillator (VCO) and a voltage signal (VC). The trip circuits operate by inhibiting the inverter and generating OFF pulses to the appropriate transistors. The inverter is also inhibited at start up for 0.3 seconds after application of the supply voltage. Conventional analogue circuits control current speed acceleration and deceleration.

Fig. 1 Inverter block diagram





Fig. 2 Typical torque/speed characteristic with standard motor




Fig. 3 Relationship between motor frequency and voltage




Fig. 4 Motor line to line voltage waveforms at 30Hz




Fig. 5 Motor current waveform at 30Hz

4. Motor Rating

4.1 STANDARD MOTOR

When the speed of a standard induction motor is reduced the speed of the cooling fan is also reduced and with it the amount of air necessary to ensure effective motor cooling. In addition because the inverter output voltage is not exactly sinusoidal the motor losses are also slightly increased. This increase in motor losses means that the motor cannot be continuously run at full load. Fig 6 shows typical continuous torques available when using a standard induction motor. To protect the motor at low speeds it should be equipped with thermal relays which can be arranged to trip the inverter via the external trip circuit (terminal 14). It is possible to use a motor of larger frame size than the rating of the inverter however it is important to check that the inverter current rating is not exceeded. Also due to the lower inductance of larger motors there is an increase in the ripple current and hence a de-rating may be necessary. As a general rule if the next frame size larger than the rated motor is used then a de-rating on inverter output current of $0.9 \times$ nominal rating should be used. For more precise information on motor ratings please consult factory.




Fig. 6 — Motor derating at reduced speed.

4.2 60Hz MOTORS

When using Jaguar with 60Hz motors it is necessary to modify the V/Hz relationship. This is done by removing link J8 (50Hz) and inserting link J9 (60Hz). See figure 7.

5. Inverter Installation

5.1 LIST OF TERMINALS

- | | | | |
|----|--|-----|--|
| L1 | 3 Phase Input
(VL Models) | 7. | Torque Control Input |
| L2 | | 8. | Frequency Error 0-14V D.C. |
| L3 | | 9. | Output Synch. Frequency
30 x Motor Frequency |
| L1 | 1 Phase Input
(VN Models) | 10. | Input Synch. Frequency
30 x Motor Frequency |
| N | | 11. | Tacho Input |
| U | Motor Connections
(VL + HVL Models) | 12. | 60V Max |
| V | | 13. | Electronics Common OV |
| W | | 14. | External Trip — Fleeting Disconnect
from OV to Trip |
| T1 | Motor Connections
(LVL — Models Only) | 15. | External Reset — Fleeting Contact
to OV to Reset |
| T2 | | 16. | Inhibit — Disconnect from OV to Inhibit |
| T3 | | 17. | Forward/Reverse — Connect to OV
to Reverse |
| 1. | Common Contact } Fault
N/O Contact } Relay
N/C Contact } 240V 3A | 18. | Ramp Output 0 to +10V |
| 4. | | 19. | Frequency Indication 0 to 10V DC
(100μA) (0 — 100Hz) |
| 5. | | 20. | Torque Indication 0 to -10V DC
(100μA) (0 — 150% Fit) |
| 6. | +10V Reference Voltage
(2mA max load) | | |

5.2 DIMENSION DETAIL (NATURALLY VENTILATED UNITS) VN75-150, VL75-370 ETC.




Fig. 7




Fig. 8

5.3 DIMENSION DETAIL (FAN COOLED UNITS) VL550-750, LVL05, HVL075-10




Fig. 9




Fig. 10

5.4 CABLE & FUSE SIZES

Model	Motor Rating	O/P Current-Cable mm ²		I/P Current-Cable mm ²		Input Fuse C.B. Rating	Signal Wiring mm ²	Voltage
VN75	0.75Kw	3.6	1.0	8.0	1.0	10A	0.75 Screen	220/ 240V
VN110	1.10Kw	4.8	1.0	11.0	1.5	15A	0.75 Screen	
VN150	1.50Kw	6.5	1.0	15.0	2.5	15A	0.75 Screen	
VL75	0.75Kw	2.1	1.0	3.0	1.0	5A	0.75 Screen	380/ 415V
VL110	1.10Kw	2.8	1.0	4.0	1.0	5A	0.75 Screen	
VL150	1.50Kw	3.8	1.0	5.5	1.0	10A	0.75 Screen	
VL220	2.20Kw	5.6	1.0	8.0	1.0	10A	0.75 Screen	
VL370	3.70Kw	8.6	1.5	12.0	2.5	15A	0.75 Screen	
VL550	5.50Kw	12.0	1.5	12.0	2.5	15A	0.75 Screen	
VL750	7.50Kw	16.0	2.5	15.0	2.5	15A	0.75 Screen	

ALL SIGNAL WIRING CONNECTED TO TERMINAL 1-20 SHOULD BE SCREENED WITH THE SCREEN CONNECTED TO EARTH AT ONE END ONLY.

5.5 MOUNTING THE INVERTER

Jaguar is designed for mounting in a control panel. The mounting brackets and fixing centres are shown in figs 7, 8, 9 and 10. The bottom bracket can be fixed and the inverter positioned before fixing in position the top bracket. Check the following before commissioning.

- Unit is mounted vertically
- Installation is free from dust, corrosive gas, and grinding fluid
- Installation is free from vibration
- The ambient temperature will not exceed -10 to +40°C
- That there is at least 100mm clear space above and below the unit.

It should be rembered about the inverter heat sink will run at temperatures up to 100°C and contact should be avoided with anything that might be harmed by these temperatures.

When mounting in an enclosure it is important to take into account the watts dissapated by the inverter to avoid an excessive rise in ambient temperature.

Table shows maximum watts dissapated by various models of inverter.


Model	VN75	VN110	VN150	VL75	VL110	VL150	VL220	VL370	VL550	VL750
Watts	42	65	100	25	35	45	85	130	160	200

An adaptor kit is available that allows the heatsink to be mounted outside the cubicle, maintaining IP54 integrity.


5.6 STANDARD CONNECTION DIAGRAM

The basic connections are shown below. Additional operational facilities are described in sections 7-18. Note 10K Ω pot preferred value.

VN MODELS



VL MODELS



6. Commissioning

WARNING

AFTER SWITCHING OFF THE INVERTER CAPACITORS REMAIN CHARGED TO A HIGH VOLTAGE FOR APPROXIMATELY 5 MINUTES. THE NEON FIGURE (FIG 7) REMAINS ILLUMINATED UNTIL THE VOLTAGE DROPS TO 100V.

6.1 STARTING A DRIVE

Set the speed control to zero, switch on A.C. supply and press RUN button. The power on L.E.D. should light immediately followed by the RUN L.E.D. after a delay of approximately 0.3 seconds. Increase speed control to maximum which is factory set to approximately 40Hz.

If the motor rotation is incorrect stop and reverse motor phases or reverse electronically (see section 7). If problems arise refer to the fault-finding chart in section 19.

The following adjustments are available to set the drive for a particular application.

6.2 ADJUSTMENTS

6.2.1 Minimum Frequency/Speed (N min)

Clockwise rotation increases frequency up to a level of 30% of the frequency set by N max.

6.2.2 Ramp Up (\hat{T})

This controls the linear rate of rise of speed/frequency control voltage. Clockwise rotation increases the rate.

The range of control is approximately 1-300 seconds for maximum speed change.

6.2.3 Ramp Down (\check{T})

This controls the linear rate of fall of the speed/frequency control voltage. Clockwise rotation increases the rate.

The range of control being approximately 1-300 seconds for maximum speed change.

The actual deceleration may be determined by the load inertia in which case the RAMP DOWN control will not be effective until it is turned further anti-clockwise. If fast deceleration is required the JAGUAR braking unit (IB1) should be used.

6.2.4 Maximum Speed/Frequency (N max)

This controls the maximum frequency available with the speed control set to maximum. It is adjustable between 40-100Hz. Clockwise rotation increases frequency.

6.2.5 Low Frequency Boost (V min)

As explained in section 3 in order to maintain constant flux at low frequencies (less than <20Hz) it is necessary to increase the motor voltage. This control varies the

amount of boost. Clockwise rotation increases the voltage at 2Hz to a maximum of 15% of a nominal motor voltage rating. It is only necessary to increase this control if insufficient torque is available at low speed. It should only be increased by the amount required, too much boost can prevent the inverter from being able to start the motor, or make the motor excessively noisy.

6.2.6 Torque Limit (I max)

This control sets the maximum potential torque that can be delivered by the motor. Clockwise rotation increases the available torque and it is adjustable between 75-150% FLT. The actual torque available at low frequencies may in fact be less than 150% FLT due to the motor characteristics. See fig 2. It also sets the maximum continuous current that the controller may deliver. Too low a setting may cause the motor to trip out on I x t overload during starting or running.

7. Reversing

The motor can be reversed electronically by connecting terminal 17 to OV (terminals 13 or 4). With terminal 17 open the phase sequence of the output terminal is U, V, W (T1, T2, T3).

The motor can be reversed electronically whilst running, the sequence of events on reversing is as follows: On reversal the motor decelerates under ramp control to zero speed when the phase sequence is electronically reversed and the motor then accelerates in the reverse direction to the set speed.

8. Speed Control Input Variations


Links J1 and J2 set input speed control parameters as follows (see fig. 7).

0 to +10v — J1 Linked, J2 Open
4-20mA — J1 Open, J2 Linked

N.B. For speed potentiometer control use a potentiometer value of 10kOhm.

9. Torque Control

The drive can be run in the torque control mode by making the following connections and removing link J4 before switching the Inverter on.



10. External Speed Signal

A voltage proportional to frequency is available between 19 and 13(OV) as follows:

0 to + 10V \pm 10% = 0-100Hz
Output impedance = 4.7k. Maximum load 100 μ A

The sync. frequency of 0-3000Hz is available between terminal 9 and 13 (OV).
Output impedance = 4.7k.

11. External Torque Signal

An external signal approximately proportional to torque is available between terminals 20 and 13(OV) as follows:

0 to -10V \pm 20% = 0-Max Torque (150% FLT)
Output impedance = 4.7k. Maximum load 100 μ A

This signal is not valid when operating in torque control mode.
Above 50Hz the max torque is reduced due to the under fluxing of the motor.

12. Tacho Generator Feedback

The speed regulation of the drive is determined by the slip of the motor (typically 4%). To achieve better regulation tachogenerator feedback can be employed. The D.C. tachogenerator should be connected between terminals 11 and 12. The voltage range that can be accepted is between 30-60v D.C. (at Max speed).

It is not necessary to observe polarity.
The following adjustment should be made to the inverter.

NO TACHOGENERATOR FEEDBACK
J6 LINKED, J7 OPEN,
R15 REMOVED
(AS DELIVERED)

TACHOGENERATOR FEEDBACK
J6 OPEN, J7 LINKED.
R15 4.7K

R15 sets the stability of the drive reducing its value increases the damping. The N MAX control still adjusts the maximum speed.

13. External Inhibit

To enable the drive to run, terminal 16 must be connected to OV (terminal 13 or 4). When this connection is open the drive is inhibited and the RUN LED is de-energised, reconnecting 16 to OV removes the inhibit.

14.External Trip


To enable the drive to run, terminal 14 must be connected to OV (terminals 13 or 4). When this connection is opened momentarily the drive will trip and the RUN LED is de-energised and the external trip LED energised. To reset the power must be removed or the external reset terminal used.

15.External Reset

Any of the five trip conditions indicated by the LED's can be reset by removing the input power from the inverter or by momentarily connecting terminal 15 to OV (terminals 13 or 4). The drive will reset after start up delay TD (0.3 seconds).

16.Frequency Synchronisation

Jaguar may be synchronised to an external frequency applied to terminal 10. Terminal 8 must be linked to terminal 7 and Link J4 removed. The external frequency must be at a frequency of $30 \times \text{MOTOR FREQUENCY}$ and at LOGIC LEVEL OF 15v. Two or more Jaguars may be synchronised together by using the frequency signal on terminal 9 as a frequency synchronising waveform for another inverter (terminal 10). The slave inverter requires a speed reference \geq to the speed of the master, this is achieved by linking terminal 18 (ramp output) of the master to terminal 5 (speed reference) of the slave and adjusting the max. speed (N max) potentiometer of the slave.



*Remove Link J4 on Slave Inverter

17.Economy Mode

With LINKJ3A (fig 7) fitted the inverter operates with a constant V/F ratio modified at low frequencies by the boost control (fig 3).

To operate in the ECONOMY MODE LINKJ3A is removed and J3B inserted. Now the V/F ratio will be dependent on the load as shown in Figure 11, at NO LOAD the motor

voltage being approx 50% of the nominal maximum value. This means the efficiency will be improved and the acoustic noise of the motor substantially reduced. Change link position only with the inverter switched off.

This mode of operation is recommended for fans and pumps or any load where rapid changes of torque do not occur.





Fig 11 Economy Mode V/f Characteristics

18.Electronic Pushbutton Control

The external trip & reset facility can be used for pushbutton control of the inverter, thus avoiding the need for an input contactor. However to achieve this the under voltage detector must be made to latch and this is done by removing link J11 and inserting link J10 (see fig 7).



19.LED Diagnostic Indicators

- 19.1 **POWER ON** Indicates voltage has been applied to terminals L1, L2 and L3 or L1 & N. Failure to light indicates supply loss or blown control fuse.
- 19.2 **RUN** Indicates drive healthy and ready to run. Lights 0.3 seconds after application of power to the inverter.
- 19.3 **OVERCURRENT** Indicates that the inverter peak current has been exceeded.
- 19.4 **OVER VOLTAGE** Indicates that the D.C. Link Voltage of the inverter has exceeded its maximum rating.
- 19.5 **OVERLOAD** Indicates operation of inverse time overload trip. Typically the trip will operate in approximately 20 seconds for $1.5 \times \text{FLT}$. Reducing the I MAX control reduces the trip level.

- 19.6 **EXTERNAL TRIP** Indicates that terminal 14 has been disconnected from OV.
- 19.7 **UNDER VOLTAGE** Indicates power supply voltage is low. This indicator flashes ON and OFF during the start up delay. With Link J11 inserted this trip does not latch. It can be made to latch by inserting Link J10. With fan cooled models this trip may also indicate overtemperature (see below).
- 19.8 **OVERTEMPERATURE** (see fig 9) Indicates that the heatsink or ambient temperature is too high. In the overtemperature condition the undervoltage L.E.D. also lights. This indicator applies to VL550/750 and all LVL/HVL models. This trip latches and must be reset after a suitable cool-down period.

20. Braking Unit (IB-1)

- 20.1 **GENERAL** The IB1 provides controlled motor braking for all Jaguar models except HVL series (440/460v supply). Braking torque is determined by remotely mounted power resistors — (supplied). Protection against excessive braking load is by thermal trip — (also supplied).
- 20.2 **SPECIFICATION** AC supply. 220-415 volt $\pm 6\%$ 50/60Hz, self adjusting reference.
DC supply. 2 wire +HT, -HT connection to Inverter — not protected.
Braking Current. 15Amp DC for 20 seconds max.
Braking Point. Factory preset. Suits LVL, VN & VL Jaguars — not HVL series.
Braking Torque. Set by remote power resistors — supplied.
Braking Duty. Normally 5 seconds every 2 minutes. Expandable.
Protection. AC supply fusing. Not protected on DC lines.
Temp Range. -10°C to +40°C.

- 20.3 **APPLICATION** For controlled braking of motor and load. The IB-1 braking system should be specified. By using power resistors of known value a defined braking torque is developed, braking time being dictated by total load inertia. The IB-1 will work correctly from an AC supply anywhere between 220-415 $\pm 6\%$ without further adjustment. It should not be used with HVL series inverters where the supply is 440/460V. The table in fig 12 shows the correct power resistor combination for all models along with resulting braking torques. Figures are quoted against a 5 second braking period every 2 minutes. This may be increased — refer to supplier. For convenience provision is made on the IB-1 for connecting the thermal trip. See fig 13.

Fig 12 Braking Resistor/Trip — Data & Connections


MODEL	VN01	VN75	VN110	VN150	VL75	VL110	VL150	VL220	VL370	VL550	VL750	LVL02	LVL03	LVL05
RESISTOR NETWORK CONFIGURATION AND WEBER TRIP VALUE T12 SERIES TYPE T12 221SN														
% MOTOR F.L.T. BRAKING - APPRX.	85	110	85	62	165	125	92	70	79	58	43	100	73	50
BRAKING DUTY — APPRX.	5 SECONDS BRAKING IN EVERY 2 MINUTES — MAXIMUM													
THERMAL TRIP TIME	15 SECONDS — NOMINAL													

NOTE: FOR EXTENDED BRAKING PERFORMANCE REFER TO SUPPLIER

The IB1 is also recommended for applications involving overhauling loads, high speed/inertial load and systems using synchronous motors.

20.4 CONNECTIONS

Fig 13




N.B. The supply to the IB-1 must be of the same value as that of the inverter.

- 20.5 **ADJUSTMENT** The Inverter must be adjusted for fast ramp-down where the IB-1 is used. The Inverter's main control p.c.b. ref IN-3, incorporates a link system, link J13 must be removed and J12 inserted for braking operation. Earlier models may not have link J12/J13, in this case add a shorting link across resistor R122 on the IN-3 p.c.b. for fast deceleration.

- 20.6 **PRINCIPLE OF OPERATION** The decelerating AC motor regenerates energy to the Inverter. Without the IB-1 system the inverter automatically extends the braking time, but in severe cases may tripout on 'over volts'. The IB-1 gives faster motor deceleration by continuously monitoring the inverter's internal D.C. link condition detecting the motor's regenerative energy as an increased D.C. link voltage. During braking the IB-1 connects the power resistor bank across the D.C. link dissipating the motor's braking energy. An on-board L.E.D. indicates the braking event. On completion of braking the IB-1 switches off. Variations in the mains supply between 220-415 volt $\pm 6\%$ are automatically compensated to maintain the correct braking point. To guard against excessive braking or fault conditions the thermal trip must always be used as shown in fig 12/13. When first connecting the IB-1 to the Inverter ensure that all internal supplies have discharged. Wiring should be of a high standard and carefully checked before switching-on since the short circuit and earth-fault protection of the inverter is not effective on the IB-1 system interconnections.


21. IN3 Block Diagram



22. Fault Finding Chart

Fault	Possible Cause	Action
Power on LED fails to light	Supply loss. Internal fuses blown	Replaces fuse. If they blow again replace Inverter
Motor will not run. Run LED fails to light	External interlock open LED lights Overcurrent fault I> LED lights	Terminals 14 & 16 must be connected to OV (4 or 13) Check motor connections for short circuit or earth fault. Reset if overcurrent trip operates again. Open circuit motor terminals. Reset. If fault remains replace inverter.
Motor will not accelerate Overload (I x t) lights after a time	Incorrect I max setting Insufficient low frequency boost Too much low frequency boost Insufficient starting torque or motor overload Missing input phase. Internal fuse blown	Check & adjust setting Increase V min control until motor accelerates Reduce V min until motor accelerates Consider using larger motor and inverter. Replace
Motor will not accelerate above 50Hz	N max control set too low Constant or rising torque load. Overload (I x t) LED lights after a time	Increase N max control Lower N max control
Over voltage U> LED lights	Very high supply voltage surge Very high inertia load LED lights only on deceleration	Reset Increase ramp down time on control T Ensure Link J12 not fitted
Over temperature LED lights (see fig 9)	Faulty fan Obstructed air outlet or inlet (see fig 10)	Rectify

IMO JAGUAR



DANGER
ELECTRIC SHOCK RISK

HEALTH AND SAFETY AT WORK

Electrical devices can constitute a safety hazard. It is the responsibility of the user to ensure the compliance of the installation with any acts or bylaws in force. Only skilled personnel should install this equipment after reading and understanding this instruction manual. If in doubt refer to your supplier.

UNITS RETURNED UNDER GUARANTEE

The manufacturer will ship and exchange an inverter on advice that a supplied unit fails to function properly. Exchange units will have a warranty protection identical to the new unit and will be invoiced at the current price.

The non-functioning inverter should be returned to the manufacturer for inspection. If the returned inverter is under warranty and is in-operable due to defects covered by the warranty then full credit will be issued. If the returned inverter is out of warranty credit equal to 25% of the sale price will be issued. If the customer requires to keep the faulty unit as a spare it will be repaired at his own cost and returned to him. Customers returning a controller should provide a purchase order and quote type and serial no.

IMO PRECISION CONTROLS LTD

1000 North Circular Road, Staples Corner, LONDON NW2 7JP

Tel. 01 452 6444 Telex 28514 Cables IMO LIMITED

Telefax 01 450 2274

ISS APRIL 85.